

## 喉頭鉗子 フレンケル氏



10313700  
先端回転式  
(鉗嘴 鋭匙状付)  
a 215 b 100




10313801  
上開 (前)  
a 215 b 95



10313802  
下開 (後)  
a 215 b 95




10313803  
左開  
a 215 b 95



10313804  
右開  
a 215 b 95



10314301  
鉗嘴  
中島氏 麦粒状  
1/1



10314300  
下咽頭鉗子  
中島氏 麦粒状  
a 210 b 70